

Windows Template

Turn over for Mac Template



To Load Preprogrammed SoftKeys:

1. Click on Interwrite Workspace icon  on Windows Task Bar and select **Devices...**
2. If Interwrite Pad is not connected, select it in list and connect it by clicking on **Connect** button.
3. With Interwrite Pad still selected, click on **Properties** button.
4. Click on **SoftKeys** tab, then click on **Import** button and select *softkey1.iwp*.

To program SoftKeys, refer to Interwrite Workspace Help.

37-01116-01/36-01257 B